



Nr./ No.	Bezeichnung	Description	Menge / Qty.	Art.-Nr. / No.
1	Spiralbehältertopf ROSPI 10	Spiral box ROSPI 10	1	H8.1814
2	Spiralbehälterdeckel.	Spiral cover cpl. ROSPI 10	1	H8.1893
3	Aufnahmeflansch	Adapter flange	1	H9.7835
4	Sechskantmutter DIN 439-M18 x 1,5-ST	Hexagon nut DIN 439-M18 x 1,5-ST	1	H8.8519
5	Zylinderschraube DIN 912 - M5 x 25-ST	Cylinder head screw DIN 912 - M5 x 25-ST	3	H8.8161
6	Scheibe DIN 125 - A5,3	Washer DIN 125 - A5,3	3	H9.8955
7	Sechskantmutter ISO 10511-M5	Hexagon nut ISO 10511-M5	3	H8.8518
8	Zylinderschraube DIN912 M5x20	Cylinder head screw DIN912 M5x20	3	H8.0615
9	Vulkanfaserscheibe DIN 7603 - A9x5x1	Vulcanized fibre washer DIN 7603 - A9x5x1	3	H9.7889
10	Moosgummiring	Foam rubber ring	1	F8.4047
11	Bohrmaschine 230 V,50/60Hz,630W,0-950U/min	Drill. machine 230 V,50/60Hz,630W,0-950 rpm	1	L2.1674
12	Scheibe DIN 9021-6-A2K	Washer DIN 9021-6-A2K	1	H9.8351
13	Senkschraube ISO 2009 M6x26-LH-ST	Counter sunk screw ISO 2009 M6x26-LH-ST	1	F8.4072
14	Steuergriff	Control handle bar	1	F8.4052
15	Lagerung kpl.	Bearing cpl.	1	F8.4053
16	Feste Rollenaufnahme	Fixed roll mounting	1	F8.4051
17	Spiralführungsrohr kpl.	Spiral guidance pipe cpl.	1	F8.4055
18	Reparatur Kit ROSPIMATIC	Repair kit ROSPIMATIC	1	F8.4046
19	Niederhalter	Downholder	1	F8.4059
20	Zustellschraube mit Rutschkupplung	Adjusting screw with friction clutch	1	F8.4020
21	Deckel	Cover	1	F8.4061X
22	Laufrolle LR50/6-2RSR	Roller LR50/6-2RSR	2	F8.4062
23	Zylinderschraube DIN 912 - M6 x 25	Cylinder head screw DIN 912 - M6 x 25	2	F8.4064
24	Paßscheibe DIN 988-6x12x0,5	Shim ring DIN 988-6x12x0,5	2	F8.4065
25	Scheibe	Washer	1	F8.4066
26	Sicherungsring DIN471-18x1,2	Retaining ring DIN471-18x1,2	1	F8.4067
27	Sechskantmutter ISO 10511-M6	Hexagon nut ISO 10511-M6	2	H8.8501
28	Schraube. DIN7505 SEKO VZ TORX 4x40	Screw DIN7505 SEKO VZ TORX 4x40	3	F8.4069
29	Pt-Schraube, Delta 40x12, WN5452	Pt-screw, Delta 40x12, WN5452	2	F8.4070

**WICHTIG!** Um die Sicherheit und Zuverlässigkeit des Produktes zu erhalten, dürfen Reparaturen, Überholungs- und Einstellarbeiten nur von ROTHENBERGER, Kelkheim oder autorisierten Service-Werkstätten ausgeführt werden. Verwenden Sie nur Original- Ersatzteile. Bestellen Sie Ihre Zubehör und Ersatzteile bei Ihrem Fachhändler oder bei unserer Hotline Service After Sales

**IMPORTANT!** To assure Safety and Reliability, repairs, maintenance and adjustment must be performed by ROTHENBERGER Kelkheim, or authorized Service-Centers, always use Original-Service-Parts. Order your accessories and spare parts from your specialist retailer or using our Service After Sales hotline

Tel. +49 6195 - 800 8200

Fax: +49 6195 - 800 7491

✉ [service@rothenberger.com](mailto:service@rothenberger.com)